




The Scotia Insert


Contents



Fireplace Fascia



Damper Plate




Cast Iron Firebrick Retaining Plate




Grate



Bars



Ashpan Cover



Damper Fixing Plate

2x M6 Bolts

2x M6 Washers


2x M6 Nuts



2x M6 Threaded Hooks



Ashpan Handle



5x M6 Washers



5x M6 Nuts



2x M6 Bolts





4x M6 Studs

Please note, a 10mm spanner is required to assemble this fireplace.

1 GAS USAGE

SOLID FUEL USAGE



Position Firebrick in place and hold in using the Cast Iron Firebrick Retaining Plate, securing with 1 x M6 Stud, Washer and Bolt.

THIS STEP IS NOT REQUIRED FOR SOLID FUEL USE

2


SOLID FUEL USAGE



Lay Fireplace Back down on level ground. Position Firebrick in place and then insert 1 x M6 Stud into the hole just below the Firebrick. Insert Grate into the groves on the Fireplace Back, passing the fixing lug over the M6 Stud. Secure in place with 1 x M6 Washer and 1 x M6 Bolt.


THIS STEP IS NOT REQUIRED FOR GAS USAGE.

3



Insert the 4 M6 Studs into the back of the Fireplace Fascia.


4




Attach Fireplace Back to the back of the Fireplace Fascia, ensuring that the M6 Studs pass through the fixing brackets on the Fireplace Back. Secure and tighten using 4 M6 Washers and 4 M6 Nuts.




The Scotia Insert





Attach 2x M6 Threaded Hooks into the Bars.



Attach Bars to the Fireplace Fascia, passing 2x M6 Threaded Hooks through the grooves. No Grate Required for Gas Usage.




SOLID FUEL USAGE




GAS USAGE

Solid Fuel Usage: Rest the Damper Plate onto the groove on the back of the Fireplace Fascia.

Gas Usage: The Damper Plate must remain fixed open for Gas Usage by using the Damper Plate fixing Kit. Screw M6 Nut fully onto M6 Bolt and lastly M6 washer x2. Attach Damper Fixing Plate as fig 1.



Attach the Ashpan Handle to the Ashpan using an M6 Washer, M6 Nut and M6 Bolt.



To complete, place Ashpan Cover below Grate and Bars on the front of the Fireplace.